

# Disposal & Dismantling

Article number: 4308797  
Light source: LT2364\_module

## **Dismantling of LED driver and light source for disposal purposes**

Firstly, disconnect the product from any power supply. Make sure that the mains power line is voltage-free – turn off safety cut-out or unscrew the protection fuse. The switch must be in OFF position. Secure it against unauthorized switching on.

Steps 1-3: Remove the screws and take the bracket from the lamp base.

Step 4: Loosen the screws on the luster terminal and disconnect the wires.

Step 5-7: Remove the wire conjunction.

Step 8: Take out the LED driver. Dispose the LED driver according to the relevant legal regulations.

Step 9: Remove the screws.

Step 10: Take the frame from the lamp base.

Steps 11-12: Remove the cover and pull out the light source from the frame. Dispose of the light source according to the relevant legal regulations.

## **Manufacturer**

DI-KA Vertriebsgesellschaft mbH & Co. KG  
Oberstrasse 4  
59755 Arnsberg  
Germany  
Tel: +49 2932 9022580  
<http://www.di-ka.net/>

