Disposal & Dismantling

Article number:4306118Light source:LT2070_3_module

Dismantling of LED driver and light source for disposal purposes

Firstly, disconnect the product from any power supply. Make sure that the mains power line is voltage-free – turn off safety cut-out or unscrew the protection fuse. The switch must be in "OFF" position. Secure it against unauthorized switching on.

- 1. Open and take off the lamp shade cover.
- 2. The light source and LED driver are located on the lamp base.
- 3. Remove the screws from the lamp base.



- 4. Remove the LED driver and light source from the lamp base.
- 5. Remove the enclosure from the LED driver.
- 6. Remove the diffusor from the light source.
- 7. The light source is now separated, but still connected with wires.
- 8. Cut the wires of the light source and LED driver.
- 9. The light source and the LED driver and can now be separately disposed of according to the relevant legal regulations.

Manufacturer

DI-KA Vertriebsgesellschaft mbH & Co. KG Oberstrasse 4 59755 Arnsberg Germany Tel: +49 2932 9022580 http://www.di-ka.net/

