


Disposal & Dismantling

Article number: 4306121
Light source: LM21-017

Dismantling of light source for disposal purposes

 Firstly, disconnect the product from any power supply. Make sure that the mains power line is voltage-free – turn off safety cut-out or unscrew the protection fuse. The switch must be in “OFF” position. Secure it against unauthorized switching on!

1. Open the terminal block and loosen the screws, then take out the cables to cut the product from the mains.
2. Remove the screws from both end caps.
3. Remove the shade from the lamp housing.
4. Remove the screws from the end cap on the light source.

The light source is now dismantled and can be disposed of according to the relevant legal regulations.

Manufacturer

DI-KA Vertriebsgesellschaft mbH & Co. KG
Oberstrasse 4
59755 Arnsberg
Germany
Tel: +49 2932 9022580
<http://www.di-ka.net/>

