

Disposal & Dismantling

Article number: 4308094
Light source: LT2070_3_module

Dismantling of LED driver and light source for disposal purposes

Firstly, disconnect the product from any power supply. Make sure that the mains power line is voltage-free – turn off safety cut-out or unscrew the protection fuse. The switch must be in "OFF" position. Secure it against unauthorized switching on.

1. Open and take off the lamp shade cover.
2. The light source and LED driver are located on the lamp base.
3. Remove the screws from the lamp base.



4. Remove the LED driver and light source from the lamp base.
5. Remove the enclosure from the LED driver.
6. Remove the diffuser from the light source.
7. The light source is now separated, but still connected with wires.
8. Cut the wires of the light source and LED driver.
9. The light source and the LED driver and can now be separately disposed of according to the relevant legal regulations.

Manufacturer

DI-KA Vertriebsgesellschaft mbH & Co. KG
Oberstrasse 4
59755 Arnsberg
Germany
Tel: +49 2932 9022580
<http://www.di-ka.net/>

